



## Cabin Filtration Product MicronAir<sup>®</sup> No. FD02155P, FD02155C

### Tools

- Standard screw driver

**1**

- Open the hood.

**2**

- Remove the windshield wiper arm nut covers. Remove the windshield wiper arm retaining nuts, then remove the wiper arms using a suitable windshield wiper arm puller.
- Disengage the cowl grille retainers, then remove the cowl grille.
- Remove the cabin filter from the cowl grille opening.

**3**

- Install a new micronAir<sup>®</sup> cabin air filter, ensuring the air flow marking is facing in the proper direction.

**4**

- Install the cowl grille, ensuring all the retainers are properly attached.
- Position the windshield wiper arms to the pivots, then install the retaining nuts and close the covers.

**5**

- Close the hood.

**This micronAir<sup>®</sup> Cabin Air Filter fits: Jaguar X-Type, from model year 2002.**

## Get in and breathe easy.

The vehicle manufacturer recommends that the filter be changed every year or 15,000 miles.  
Engineered for Original Equipment Manufacturer Specifications.