



## Cabin Air Filtration Product MicronAir® No. VW94157C

**1**

- Open hood.

**2**

- Locate filter housing on underside of hood.
- Press in quick lock retainer and turn 90 degrees.

**3**

- Remove the cabin filter by pulling it straight down. Install a new cabin filter.

**4**

- Replace housing, press in quick lock retainer and turn.

**This MicronAir® Cabin Air Filter fits: Audi A8, from model year 1994.**

# Get in and breathe easy.

*The vehicle manufacturer recommends that the filter be changed every year or 15,000 miles.  
Engineered for Original Equipment Manufacturer Specifications.*